



**Performance Oil Catch Can Kit
Part Number: 860-002**

**Honda 2017-2021 Civic Type R 2.0L Turbo
Left Hand Drive ONLY
2024 Acura Integra Type S 2.0L Turbo**

Installation Instructions

For technical inquiries please email us at tech@hpsperformanceproducts.com

In the email, please include the following information for faster response:

- Year / Make / Model / Engine of your vehicle
- If it is a fitment issue, please include pictures showing the fitment problem
- If there are missing parts, please list the part number(s) from the bill of materials on the 2nd page
- Optional but recommended – Your contact phone number and preferred call back time

You can also give us a call via 626-747-9200 for tech support Monday-Friday, 9:00am-5:00pm Pacific Time.

Bill of Materials

Kit Number: 860-002

Line #	Description	Part Number	Qty
1	Oil Catch Can	OCC-12	1
2	Oil Catch Can Bracket	OCC-BRKT-002	1
3	Bolt, M5 x 0.8, 10mm Long	HW-B5-10	3
4	Fuel Injection Clamp 13mm - 15mm	FIC-13	2
5	-6 to 16mm x 1.50 Straight Aluminum Adapter	AN816-6-M1615	2
6	Inlet Hose	HOSE-86-103	1
7	Outlet Hose	HOSE-86-104	1

- Before installing any parts, please read the instructions thoroughly.
- Verify the contents of this kit before disassembling your vehicle.
- **DO NOT INSTALL IF ANY PARTS ARE MISSING OR DAMAGED. CONTACT tech@hpsperformanceproducts.com IMMEDIATELY. WE ARE NOT RESPONSIBLE FOR ANY DAMAGE CAUSED DUE TO IMPROPER INSTALLATION.**
- Installation requires moderate mechanical skills. A qualified mechanic is highly recommended.
- Do not attempt to install the oil catch can while the engine is hot.
- This installation may require removal of coolant lines that may be hot.

- For technical inquiries, please email us at tech@hpsperformanceproducts.com.

PLEASE READ CAREFULLY BEFORE INSTALLATION!

This installation is not for the novice customer. Install this product with EXTREME caution! Misuse of this product can destroy your engine! If you are not mechanically inclined, please have a professional automotive mechanic install this kit.

NOTE: HPS holds no responsibility for any engine damage that results from misuse of this product.


GETTING STARTED

1. Turn the ignition OFF and disconnect the vehicle's negative battery cable. If the engine has run within the past two hours let it cool down.


NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is reconnected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicles' anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicle's anti-theft code. We also highly recommend NOT discarding any stock parts after the installation.




2. Remove the 5 bolts securing the engine cover and remove it from the vehicle.




3. Disconnect and remove the PCV hose from the valve cover and the intake manifold.



4. Remove the two 10mm bolts securing the fuel hose cover and remove it from the vehicle.




5. Carefully remove the fuel line assembly from the retaining clips.



6. Remove the two 10mm bolts securing the fuel line assembly bracket to the firewall.



7. Insert the HPS oil catch can bracket behind the fuel line assembly bracket and secure it reusing the factory bolts.




8. Reinstall the fuel line assembly back into the retaining clips.



9. Reinstall the fuel hose cover using the factory bolts.



10. Slide the provided FIC-13 clamp onto the pre-assembled outlet hose as shown.




11. Connect and secure the hose to the intake manifold.




12. Slide the provided FIC-13 clamp onto the pre-assembled inlet hose as shown.




13. Connect the hose to the valve cover.




14. Fasten the FIC-13 clamp.




15. Before proceeding further, unscrew the can from the top half of the HPS oil catch and check to make sure the Allen bolts are securely fastened. Reassemble the catch can once the screws have been fastened.



16. Secure the two -6 AN to M16 x 1.5 adapter fittings along with the provided crush washers onto the HPS oil catch can.



17. Secure the HPS oil catch can to the HPS catch can bracket using the provided M5 Allen bolts (3).



18. Connect and secure the hose ends onto the oil catch can.

FINAL STEPS

Upon completion of the installation, reconnect the negative battery terminal before you start the engine. Double check to make sure everything is tight and properly positioned before starting the vehicle.

Reinstall the engine cover using the stock hardware.

Start the engine. Let the car idle for 3 minutes. Perform a final inspection before driving. Listen carefully for any odd noises or rattles prior to taking it for a test drive. If any problems arise, go back and check the hoses and clamps that may be causing the issue and correct the problem.

Ensure that the dipstick on the HPS oil catch can is fully seated. Failure to install the dipstick properly will result in a check engine light and poor performance.



Also available for Honda 2017-2021 Civic Type R 2.0L Turbo



HPS Performance Front Strut Bar
Part Number [42-111](#)



HPS Performance Silicone Intake Kit
Part Number [57-1765](#)



**HPS Performance Stainless Steel Magnetic
Oil Drain Plug**
Part Number [MDP-M14x150](#)



HPS Performance Intercooler Charge Pipe Kit
Part Number [17-133](#)

Contact an authorized HPS Performance dealer or
visit us at hpsperformanceproducts.com for more details