



Performance Oil Catch Can Kit

Part Number: HPS-OCC-001

Honda 2018-2022 Accord 2.0L Turbo

Installation Instructions

For technical inquiries please email us at tech@hpsperformanceproducts.com

In the email, please include the following information for faster response:

- Year / Make / Model / Engine of your vehicle
- If it is a fitment issue, please include pictures showing the fitment problem
- If there are missing parts, please list the part number(s) from the bill of materials on the 2nd page
- Optional but recommended – Your contact phone number and preferred call back time

You can also give us a call via 626-747-9200 for tech support Monday-Friday, 9:00am-5:00pm Pacific Time.

Bill of Materials

Kit Number: HPS-OCC-001

Line #	Description	Part Number	Qty
1	Oil Catch Can	OCC-12	1
2	Oil Catch Can Bracket	OCC-BRKT-001	1
3	Bolt, M5 x 0.8, 10mm Long	HW-B5-10	3
4	Fuel Injection Clamp 13mm - 15mm	FIC-13	2
5	-6 150 Series AN Hose x 10.5 inches in Length	150-06	1
6	-6 150 Series AN Hose x 7.25 inches in Length	150-06	1
7	-6 150 Series AN Hose x 2 inches in Length	150-06	1
8	3/8" Check Valve	CV-038	1
9	-6 to 16mm x 1.50 Straight Aluminum Adapter	AN816-6-M1615	2
10	-6 90 Degree 150 Series Push-On Aluminum Hose End	150-9006	1
11	-6 45 Degree 150 Series Push-On Aluminum Hose End	150-4506	1

- Before installing any parts, please read the instructions thoroughly.
- Verify the contents of this kit before disassembling your vehicle.
- **DO NOT INSTALL IF ANY PARTS ARE MISSING OR DAMAGED. CONTACT tech@hpsperformanceproducts.com IMMEDIATELY. WE ARE NOT RESPONSIBLE FOR ANY DAMAGE CAUSED DUE TO IMPROPER INSTALLATION.**
- Installation requires moderate mechanical skills. A qualified mechanic is highly recommended.
- Do not attempt to install the oil catch can while the engine is hot.
- This installation may require removal of coolant lines that may be hot.
- For technical inquiries, please email us at tech@hpsperformanceproducts.com.

PLEASE READ CAREFULLY BEFORE INSTALLATION!


This installation is not for the novice customer. Install this product with EXTREME caution! Misuse of this product can destroy your engine! If you are not mechanically inclined, please have a professional automotive mechanic install this kit.

NOTE: HPS holds no responsibility for any engine damage that results from misuse of this product.


GETTING STARTED

1. Turn the ignition OFF and disconnect the vehicle's negative battery cable. If the engine has run within the past two hours let it cool down.

NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is reconnected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicles' anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicle's anti-theft code. We also highly recommend NOT discarding any stock parts after the installation.



2. Lift and remove the engine cover.




3. Disconnect and remove the PCV hose from the valve cover and the intake manifold.



4. Remove the two 10mm bolts securing the fuel hose cover and remove it from the vehicle.




5. Remove the two 10mm bolts securing the fuel line assembly bracket.



6. Insert the HPS oil catch can bracket behind the fuel line assembly bracket and secure it reusing the factory bolts.




7. Reinstall the fuel hose cover using the factory bolts.



8. Before proceeding further, unscrew the can from the top half of the HPS oil catch and check to make sure the allen bolts are securely fastened.



9. Secure the two -6 AN to M16 x 1.5 fittings along with the provided crush washers onto the HPS oil catch can.




10. Secure the HPS oil catch can to the bracket using the provided M5 allen bolts (3) with the fittings facing the fuel line assembly.



11. Slide the provided FIC-13 clamps onto the pre-assembled hose with 90 degree fitting.


0



12. Connect the hose to the intake manifold before connecting the 90 degree AN fitting onto the port located closest to the firewall. Position the fitting to ensure at least $\frac{1}{8}$ " of clearance between the fitting and the fuel hard line, then secure the fitting.



13. Slide the provided FIC-13 clamp onto the hose with the pre-assembled 45 degree fitting.



14. Connect the hose to the valve cover then connect the fitting onto the oil catch can. Check that the position of the fitting sits nicely between the engine cover and fuel hose cover before fastening.




15. Reinstall the engine cover back onto the vehicle.

FINAL STEPS

Upon completion of the installation, reconnect the negative battery terminal before you start the engine. Double check to make sure everything is tight and properly positioned before starting the vehicle.

Start the engine. Let the car idle for 3 minutes. Perform a final inspection before driving. Listen carefully for any odd noises or rattles prior to taking it for a test drive. If any problems arise, go back and check the hoses and clamps that may be causing the issue and correct the problem.

Ensure that the dipstick on the HPS oil catch can is fully seated. Failure to install the dipstick properly will result in a check engine light and poor performance.




Also available for Honda 2018-2022 Accord 2.0L Turbo



HPS Performance Front Strut Bar
Part Number [42-104](#)



HPS Performance Air Intake Kit
Part Number [827-656](#)



HPS Performance Drop In Air Filter
Part Number [HPS-457348](#)



HPS Performance Intercooler Charge Pipe Kit
Part Number [17-141](#)

Contact an authorized HPS Performance dealer or
visit us at hpsperformanceproducts.com for more details